Rotary blade level indicator
Level limit switch for bulk goods

DF

Operating instructions

Index **Page**

Safty instructions **02**

Operating instructions

1. Description **03**
2. Installation **03**
3. Electrical connection **04**
4. Switching logics and function displays **04**
5. Setting of the sensitivity **05**
6. Utilization **05**
7. Maintenance and servicing **05**
8. Storage **05**
9. Disposal **05**

Dimensions **06**

EU-Declaration of Conformity **07**

Congratulation, we felicitate to your good choise. You have decided for a first class branded product, a rotary blade level indicator from the company MOLLET.

It satisfies highest international standards:

Functionality, versatileness, long service life and design

Thank you for having decided for our product.

MOLLET Füllstandtechnik GmbH

Competence in rotation

▶ **Read and follow these safety instructions first and take notice of the operating instructions.**

Safety instructions

1.1 The installation, initial operation and maintenance may be done by a qualified expert with electrical know-how only.

1.2 The connection of the single components as like as measuring blade, anti-buckling protection, shaft extension are permissible only with the attached pins.

1.3 For the electrical connection take notice of the local and statutory rules and regulations and/or the VDE 0100.

1.4 Before electrical connection, compare the supply voltage with the details at the data plate.

1.5 A fuse (with max. 4 A) has to be connected in series to the voltage supply.

1.6 Protect the signal contacts from voltage peaks when inductive loads are connected.

1.7 The device may put into operation with built-in cap-sealing and when it is closed, only (touchdangerous voltage).

1.8 Switch off the power supply, before opening the device (touchdangerous voltage).

Cable entry

2.1 The level indicator will be delivered with a cable gland M20x1.5.

2.2 The second drill-hole is closed with a plug screw M20x1.5. Optional a further cable gland can be delivered.

2.3 The cable gland and the plug screw were screwed on at the factory. Please check if the cable gland or the plug screw have loosened during the mounting or the transportation. If so, tighten it again.

2.4 The cable gland will be delivered with a PE sealing disc. With it, the level indicator is protected against dust and dirt entry during transportation and storage. When the indicator is brought into the dusty area it has to be installed immediately at its designated place, the PE sealing disc has to be removed, a cable has to be pulled into the cable gland and the pressure screw has to be screwed on to maintain the type of protection.

ATTENTION
Excessive screw on may injure the type of protection.

▶

By use in explosive hazardous areas read and follow the

special conditions and instructions for safe application

off the attached

explosive protection information

first an take notice of the operating instructions.

Operating instructions

1. Description

1.1 Intended use

The electromechanical level limit switch is monitoring the filling level of bulk goods in silos, bunkers, containers, hoppers, weighers, etc..

1.2 Construction



1.3 Function

The rotating measuring blade, projecting into the silo or container, is driven by a gearmotor.
If the bulk material is reaching the measuring blade, the rotation will be hindered and it will be stopped.
The return torque turns the pivoted motor from its end position and actuates the signal switch. A second switch turns the motor off.
If the filling level of the bulk material sinks, the blade becomes freely again and a spring will turn back the motor into its original end position.
Thereby the motor will be turned on again and the signal switch will be switched back.

1.4 Technical data

Manufacturer		**MOLLET Füllstandtechnik GmbH**
Address		Industriepark RIO 103 74706 Osterburken
Name		rotary blade level indicator
Type		**DF**
Bulk goods temperature		T_S see data plate
Ambient temperature		T_a -20 °C ... +70 °C
Pressure range		p see data plate
Measuring blade speed		1 U/min
Response delay		approx. 1.20 sec.
Maintenance		none

1.5 Materials

Housing		aluminium
	or	stainless steel 1.4401
Process connection		aluminium
	or	stainless steel 1.4301
Blade shaft		stainless steel 1.4301
Measuring blade		stainless steel 1.4301
Sealing ring (order code)	**R0**	NBR, black
	R1	Viton/Teflon/VA
	R2	NBR, white, FDA conform
	R5	Teflon

2. Installation

2.1 Preparation

- Read and follow the safety instructions and the operating instructions before mounting the device!
- Inspect if the delivery is complete.
  The delivery volume is different, depending on the options.

2.2 Mounting

Thread connection

Put the level indicator together with the sealring at the provided position in the silo or container wall and screw it tightly by means of appropriate tools.

2.3 Mounting of the measuring blades



Attention!

During beating the pin into the shaft, you have to support the shaft with an adequate counterpart.



2.4 Orientation of the housing

After mounting, the housing has to be orientated by turning in such a away, that the cable gland is directed towards the cable duct.



Cable gland in direction to the cable duct

Attention!

Ensure that the cable is fixed tightly in the cable gland.

3. Electrical connection

3.1 Electrical data

Supply voltage		see data plate
Power consumption	*Supply*	**AC** 3.5 VA **DC** 3.5 W
Cable entry		cable gland M20 x 1.5
Type of protection	*IP*	IP 66 acc. to DIN 60529
Connection clamps		max. 1.5 mm²
Signal contact	*Contact*	change-over contact potentialfree
Switching voltage		4 V DC ... 250 V AC
Capacity of the contact		1mA ... 2A

The signal contact is a multivoltage and multicurrent switch. It is suitable for use in circuits with low currents and low voltages as well as for medium currents with control voltages up to 250 V ~AC.

Caution!

During the whole working life, the switch may be used in the same kind of circuit types, only.
When the switch has been used once with medium switching capacity, it cannot be used any more for the low switching capacity.

3.2 Electrical connection

- Install the wiring and electrical connection in compliance with the circuit diagrams.
- Run the cable between housing and cable protection, in order that the switches and the motor will not be hampered at their necessary movement.
- After the electrical connection the cap nut of the cable gland has to be screwed and please ensure that the cable is fixed strongly and tightly in the cable screwing.

3.3 Circuit diagram **AC**



3.4 Circuit diagram **DC**



Attention!

Wiring of the level indicator in a way that no undesirable switching function can occur in case of mains voltage failure.

4. Switching logics and function displays

Symbol signification

- = under voltage
- = full
- = empty
- = LED "OFF"
- = LED "ON"

Arrangement and colours of the LEDs for function display

yellow ● ● green

● green

Switching logics



5. Setting of the sensitivity

As occasion demands, the sensitivity of the level indicator can be adjusted, referring to the characteristics of the bulk goods, by shifting the spring arm.



Three settings are possible:

1.	**light**	for very light bulk goods
2.	**medium**	suitable for almost all bulk goods
3.	**strong**	for sticking bulk goods

Fluidised bulk goods are lighter during filling and draining process. This has to be taken appropriately into consideration when setting the spring force and selecting the size of the measuring blade.

6. Utilization

6.1 Putting into operation

- Commissioning of the rotary blade level indicator only, if the installation will be done correctly and if it will be fixed tightly with the electrical contact.
- During operation, the housing and the cable entry must be closed tightly.

6.2 Normal operation

- Use the rotary blade level indicator in its intended application only.
- Operate the level indicator within the intended temperature ranges for the ambient and bulk goods temperature.
- Protect the inside of the control head from soiling.
- When the indicator has to be damaged, you have to take the device out of operation immediately.

6.3 Inexpert handling

- Ignoring of the safety instructions and the operating instructions.
- Utilization of the rotary blade level indicator in not intended use.
- Mounting of spare parts which are no original parts.
- Remove, adding or change of assembling parts, unless this has been described in the documents of the manufacturer.
- Violation against applicable law and standards.

7. Maintenance and servicing

7.1 Maintenance

- In case of intended use, the rotary blade level indicator needs no maintenance.
- Remove deposits and stickings from the blades or wrinkles with a brush or with a scraper.
  Don´t use any force and don´t damage the sealring of the shaft.
- Inspect the assemblings inside of the container about signs of wear and tear, in regular intervals. Define the intervals of the control, depending on the bulk goods characteristics.

7.2 Servicing

- Damaged parts, contacts or connections have to be repaired immediately or being replaced with parts of the same kind.
- Until the complete restoration of the proper function, the rotary blade level indicator must not be used any more.

8. Storage

- While storage, the level indicator has to be protected from dust and humidity.
- Please ensure that the shaft of level indicators with jib extension will not be buckled or bended.

9. Disposal

- The level indicator can be recycled.
- The disposal applies to the valid environmental guidelines according to the location of the carrier and the local manufacturing conditions.

Dimensions



with measuring blade adapter M7



without housing (on mounting plate)



Application instructions

Mounting position **vertical**

Loadability of the blades F_1 max. **50 Nm**



Planning information

Pipe thread DIN EN ISO 228-1

DIN ISO 228-1 (substitution for DIN 259)

Thread G	Outside Ø mm	Mother-inner Ø mm	Core hole Ø mm	Pitch per Insch	Inclination mm
G 1/8	9.73	8.85	8.80	28	0.907
G 1/4	13.16	11.89	11.80	19	1.337
G 3/8	16.66	15.39	15.25	19	1.337
G 1/2	20.95	19.17	19.00	14	1.814
G 3/4	26.44	24.66	24.50	14	1.814
G 1	33.25	30.93	30.75	11	2.309
G 1 1/4	41.91	39.59	39.25	11	2.309
G 1 1/2	47.80	45.48	45.25	11	2.309
G 2	59.61	57.29	57.00	11	2.309
G 2 1/2	75.18	72.86	72.60	11	2.309
G 3	87.88	85.56	85.30	11	2.309
G 3 1/2	100.33	98.01	97.70	11	2.309
G 4	113.03	110.71	110.40	11	2.309
G 4 1/2	125.73	123.41	123.10	11	2.309
G 5	138.43	136.11	135.70	11	2.309
G 6	163.83	161.51	161.20	11	2.309





All couplings and pinch valves supplied by MOLLET are manufactured for cylindric connections with **not** metallically sealed threads.

The same applies to the level indicators DF and MWF.

Tightness is achieved by seal rings.

Tightness can also be achieved e.g. with O-rings or sealant adhesive.

According to measurement charts the threads G acc. to DIN EN ISO 228-1 (substitution for DIN 259) have the same dimensions like the threads R acc. to DIN EN 10226-1 (substitution for DIN 2999). However, the tolerances acc. to DIN EN 10226-1 are for the inner diameter in the lower and for the outside diameter in the upper area.

It is therefore possible that cylindric male threads G acc. to DIN EN ISO 228-1 can not be screwed in parts (sleeves) with female threads R that are manufactured acc. to DIN EN 10226-1.

EU-Konformitätserklärung
EU Declaration of Conformity

Drehflügel-Füllstandmelder / Rotary blade level indicator

Produkt / Product	Version
MOLOSroto	DF11, DF21, DF22, DF23, DF24, DF245, DF25, DF257, DF26, DF27, DF28, DF30, DFAS

MOLLET Füllstandtechnik GmbH erklärt hiermit in alleiniger Verantwortung, dass die Produkte mit den aufgeführten Richtlinien übereinstimmen. Diese Konformitätserklärung gilt nur in Zusammenhang mit den gültigen Betriebsanleitungen und Sicherheitshinweisen der MOLLET Füllstandtechnik GmbH.

MOLLET Füllstandtechnik GmbH hereby declares under its sole responsibility that the products comply with the listed directives. This declaration of conformity only applies in conjunction with the valid operating instructions and safety instructions of MOLLET Füllstandtechnik GmbH.

Richtlinie / Directive		angewandte harmonisierte Normen oder normative Dokumente / applied harmonized standards or normative documents
EMC	2014/30/EU	EN IEC 61326-1:2021 EN IEC 61000-6-2:2019
LVD	2014/35/EU	EN 61010-1:2010 + A1:2019 + A1:2019/AC:2019

Geräte mit Ex - Kennzeichnung entsprechen zusätzlich folgender Richtlinie:
Devices with Ex - labelling also comply with the following directive:

Richtlinie / Directive		variantenabhänig angewandte harmonisierte Normen oder normative Dokumente / depending on variant applied harmonized standards or normative documents	
ATEX	2014/34/EU	EN IEC 60079-0:2018/AC:2020-02 EN 60079-1:2014 EN 60079-7:2015 EN 60079-31:2014	EN 1127-1:2019 EN ISO 80079-36:2016 EN ISO 80079-37:2016

EU-Baumusterprüfbescheinigungsnummer /
EU-Type Examination Certificate No.: **IBExU04ATEX1001X** **IBExU04ATEX1033X**
IBExU04ATEX1010X **IBExU04ATEX1034**

Ausgestellt von / Issued by: IBExU Institut für Sicherheitstechnik GmbH, 09599 Freiberg (0637)

Qualitätssicherung /
Quality assurance: TÜV AUSTRIA GMBH, Deutschstraße 10, 1230 Wien / Austria (0408)

MOLLET Füllstandtechnik GmbH
Industriepark RIO 103
74706 Osterburken
DEUTSCHLAND

Osterburken, 12.08.2024

Wolfgang Hageleit
Geschäftsführer / Managing director

MOLLET Füllstandtechnik GmbH D-74706 Osterburken ExBH